



TXR/TXA TRENDSETTER

Installation Manual



OVERVIEW

The TXR/TXA series of transmitters consists of two systems, the TXR, Radial Vibration Transmitter System and the TXA, Thrust Transmitter System. Both systems contain three parts – a proximity probe, a matched extension cable and a transmitter. Both systems provide a 4 to 20 mA current loop output signal.

The TXR Vibration Transmitter System measures the radial vibration of a shaft or other part of a machine in relation to the location of the probe tip.

The following equation represents the relationship between the vibration and the loop current.

$$\text{Vibration} = \frac{(\text{Current (mA)} - 4)}{16} \times (\text{Full Scale Range})$$

The TXA Axial Thrust Transmitter System measures the distance between the target and the probe tip. The following equation represents the relationship between the target's relative position and the loop current.

$$\text{Absolute Distance} = \frac{(\text{Current (mA)} - 4)}{16} \times (\text{Range}) + 20$$

$$\text{Relative to 50 mil gap} = \frac{(\text{Current (mA)} - 12)}{8} \times (\text{Range} / 2)$$

For 5mm & 8mm probes range = 60 mils
and 11 mm probes range = 140 mils

Both transmitters provide a voltage proportional to the distance between the target and the probe tip. This voltage is available

as a buffered output on the BNC connector for use when gapping the probe and for diagnostic purposes. You may apply this voltage to any battery-powered or ground isolated instrumentation with a 1 MΩ or greater input impedance.

The amplitude of the output signal is +200 mV/ mil. The amplitude of a system using an 11 mm probe is 100mV/mil.

The Dynamic Output signal is buffered however, due to the limited current available on the loop; the DYNAMIC OUTPUT reading will be attenuated by instrumentation with an input impedance of less than 1 MΩ, see Graph 1.

RECEIVING, INSPECTING, AND HANDLING THE SYSTEM

The probe, extension cable, and transmitter are shipped as separate units and must be interconnected at the installation site by the user. Carefully remove all equipment from the shipping containers and inspect it for shipping damage. If shipping damage is apparent, file a claim with the carrier and submit a copy to Metrix Instrument Co. Include part numbers and serial numbers on all correspondence. If no damage is apparent and the equipment is not going to be used immediately, return the equipment to the shipping containers and reseal until ready for use. Store the equipment in an environment free from potentially damaging conditions such as extreme temperature, excessive humidity, or a corrosive atmosphere.

INSTALLATION

1. For radial vibration measurements, mount the probe with its axis radial to the shaft with its tip approximately .050" (1.25 mm) from the surface of the shaft. The probe tip must be provided with sufficient clearance from surrounding metal to prevent an erroneous output. As a minimum, the clearance diameter should be .63" (16 mm) for the full length of the probe tip. For an 11mm probe, the minimum clearance should be .88" (22mm). See Figure 1. For exact gapping procedure see the section concerning calibration. To prevent cross-feed between two probes mounted in the same vicinity, at least 1" (25 mm) spacing between the probe tips should be maintained. See Fig. 2 & 3.

2. For position (thrust) measurements, mount the probe with its axis parallel to the shaft and with its tip approximately .050" (1.25 mm) from the end of the shaft. For 11mm diameter probes, this distance is approximately .090". See the section concerning calibration for exact gapping procedure. To prevent cross-feed between two probes mounted in the same vicinity, at least 1" (25 mm) spacing between the probe tips should be maintained. For 11mm probes, this distance is approximately 2" (50mm).

3. The probe can be mounted in a simple bracket, such as the Model 7646, in a tapped hole in the bearing cap or by means of a Model 5499 Probe Housing. The latter arrangement provides an easy way to adjust the probe air gap, especially where the target is some distance from the outside surface of the machine.

4. When inserting the probe through the machine case or bearing cap, the signal voltage may vary widely before the proper gap is obtained. Therefore, be sure the gap is within .07" (1.8 mm) of the target before attempting to set the gap electrically. If possible, set the probe gap while the machine is shutdown, to avoid the danger of damaging the probe in the event that it touches the shaft.

5. Connect the probe to the transmitter using the proper coax extension cable. The standard probe configurations are shown on page 14. Do not change the length of the extension cable from the system, as such action will adversely affect the calibration and linearity. If a connector must be replaced, the overall length of the cable can be reduced by 2" without harm. Insulate the probe connector/extension cable connector junction with the Metrix 8973 connector insulator.

INSTALLATION DRAWINGS




Fig. 1




Fig. 2




Fig. 3





Fig. 4

MOUNTING THE TRANSMITTER

Mount the transmitter in a suitable enclosure in a location that is compatible with its environmental specifications. Refer to page 10 for the environmental specifications for the transmitter. The transmitter comes as a DIN rail mount. The below drawing shows the unit with the optional flat base mounting plate, part number 9647.

OUTLINE & DRAWINGS




Route the extension cable using the following guidelines:

- Check that the Transmitter, extension cable, and probe belong to the same system.
- Secure the extension cable to supporting surfaces or place in conduit. Make certain the cable is not kinked, scraped, nor bent beyond the minimum recommended radius of 1".
- Secure coaxial connectors between the extension cable and the proximity probe. Connection should be "finger tight" with an additional quarter turn using an open ended 9/32" wrench or equivalent.

- Insulate the connection between the probe lead and the extension cable by wrapping the connector with Teflon tape.

Connect the field wiring (up to 16 AWG) in accordance with the appropriate diagrams on following page. The minimum power supply voltage is 17 V plus 1 volt for each 50 ohms of loop resistance. See Graph 1.



Graph 1: Trendsetter Maximum Loop Resistance

INTRINSICALLY SAFE INSTALLATION IN HAZARDOUS LOCATIONS





Intrinsically Safe
 Class I, Div. 1, Groups A, B, C, D
 Temp Code T4 (-40°C ≤ Ta ≤ +85°C)

Connect the field wiring in accordance with Metrix drawing 9688 (page 1) for CSA Class I, Div 1 installations. The transmitter requires a minimum of 17 VDC for proper operation. The voltage drop across the specified zener barriers on the installation drawings with a 20 mA loop current is 8.1 VDC. The minimum loop power supply voltage required is 25.1 VDC plus 1 volt for each 50 ohms of loop resistance. The maximum loop power supply voltage that may be applied to the safety barrier is 26 VDC. Therefore, the maximum loop resistance with a 26 VDC supply is 45 ohms.

Example: Single wire resistance = 5 ohms
 Resistance of receiver = 50 ohms
 Total loop resistance = 55 ohms
 Minimum supply voltage = 55 (1V/50 ohms) + 25.1 V = 26.2 VDC

INTRINSICALLY SAFE INSTALLATION

CSA



NOTES:

- SAFE AREA APPARATUS IS NOT SPECIFIED EXCEPT THAT IT MUST NOT BE SUPPLIED FROM NOR CONTAIN IN NORMAL OR ABNORMAL CONDITIONS A SOURCE OF POTENTIAL WITH RESPECT TO EARTH IN EXCESS OF 250 Vrms OR 250 Vdc.
- THE TRANSMITTER ENTITY PARAMETERS ARE:

$$\begin{aligned} V_{max} &= 28V \\ I_{max} &= 93mA \\ C_i &= 18nF \\ L_i &= 0uH \\ P_i &= 0.66W \end{aligned}$$

CHOOSE A CSA CERTIFIED BARRIER WITH ENTITY PARAMETERS THAT SATISFY THE FOLLOWING CONDITIONS:

$$\begin{aligned} V_{max} &\geq V_{oc} \\ I_{max} &\geq I_{sc} \\ C_i + C \text{ cable} &\leq C_a \\ L_i + L \text{ cable} &\leq L_a \\ P_i &\geq P_o \end{aligned}$$

SUITABLE BARRIERS INCLUDE:

- MTL 7087+
- SUITABLE GALVANIC ISOLATION SAFETY BARRIERS INCLUDE: STAHL 9303/11-22-11.

- INSTALL IN ACCORDANCE WITH THE APPROPRIATE NATIONAL ELECTRICAL REQUIREMENTS AND PER THE BARRIER INSTRUCTIONS.
- THE TRANSMITTER MUST BE INSTALLED IN A SUITABLE ENCLOSURE ACCEPTABLE TO THE LOCAL INSPECTION AUTHORITY HAVING JURISDICTION.

⑤ THE TRANSMITTER PROBE ENTITY PARAMETERS ARE:

$$\begin{aligned} V_{oc} &= 5.36V \\ I_{sc} &= 3.61mA \\ C_a &= 512pF \\ L_a &= 1000uH \\ P_o &= 19.4mW \end{aligned}$$

THE SERIES 10,000 PROBE TOGETHER WITH ITS 7402 EXTENSION CABLE AND 8093 CONNECTOR INSULATOR MAY BE REPLACED BY ANY CSA CERTIFIED INTRINSICALLY SAFE PROBE THAT SATIFIES THE FOLLOWING CONDITIONS:

$$\begin{aligned} V_{max} &\geq V_{oc} \\ I_{max} &\geq I_{sc} \\ C_i + C \text{ cable} &\leq C_a \\ L_i + L \text{ cable} &\leq L_a \\ P_i &\geq P_o \end{aligned}$$

AGENCY APPROVED PRODUCT
DO NOT DEVIATE FROM
DOCUMENTATION OR
LISTED PARTS

UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. ALL CORNERS ARE 45° UNLESS OTHERWISE SPECIFIED.	DATE: 11-28-2018	SCALE: 5/8"=1"	PROJECT: 18762
THE DOCUMENT AND ALL INFORMATION HEREON ARE THE PROPERTY OF METRIX INC. APPROVAL MUST BE OBTAINED BEFORE IT IS REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS. THIS DOCUMENT ISSUED TO A THIRD PARTY. THIS DOCUMENT MUST BE RETURNED UPON REQUEST.	DESIGNED BY: J. B. BROWN	DRAWN BY: J. B. BROWN	DATE: 5-8-2020
UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. ALL CORNERS ARE 45° UNLESS OTHERWISE SPECIFIED.	DATE: 11-28-2018	SCALE: 5/8"=1"	PROJECT: 18762
THE DOCUMENT AND ALL INFORMATION HEREON ARE THE PROPERTY OF METRIX INC. APPROVAL MUST BE OBTAINED BEFORE IT IS REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS. THIS DOCUMENT ISSUED TO A THIRD PARTY. THIS DOCUMENT MUST BE RETURNED UPON REQUEST.	DESIGNED BY: J. B. BROWN	DRAWN BY: J. B. BROWN	DATE: 5-8-2020



NOTES:

1. THE MAXIMUM OUTPUT VOLTAGE FROM THE SAFE AREA APPARATUS MUST NOT EXCEED THE RATED VOLTAGE OF THE TRANSMITTER: 30VDC.
2. CIRCUIT IN HAZARDOUS AREA MUST BE CAPABLE OF WITHSTANDING A VOLTAGE TEST OF 500 VRMS TO EARTH OR TO THE FRAME OF THE APPARATUS. USE 8093 INSULATOR ON CONNECTOR BETWEEN PROBE AND EXTENSION CABLE.
3. THE INSTALLATION MUST COMPLY WITH THE APPROPRIATE NATIONAL INSTALLATION REQUIREMENTS.
4. THE TRANSMITTER MUST BE INSTALLED IN A SUITABLE ENCLOSURE ACCEPTABLE TO THE LOCAL INSPECTION AUTHORITY HAVING JURISDICTION.

⑤ THE TRANSMITTER PROBE ENTITY PARAMETERS ARE:


$V_{oc} = 5.36V$
 $I_{sc} = 3.61mA$
 $C_o = 512\mu F$
 $L_o = 1000\mu H$
 $P_o = 19.4mW$

THE SERIES 10,000 PROBE TOGETHER WITH ITS 7402 EXTENSION CABLE AND 8093 CONNECTOR INSULATOR MAY BE REPLACED BY ANY CSA CERTIFIED INTRINSICALLY SAFE OR NON-INCENDIVE PROBE THAT SATISFIES THE FOLLOWING CONDITIONS:

$V_{max} \geq V_{oc}$
 $I_{max} \geq I_{sc}$
 $C_i + C \text{ cable} \leq C_o$
 $L_i + L \text{ cable} \leq L_o$
 $P_i \geq P_o$


THE TRANSMITTER PROVIDES A NON-INCENDIVE CIRCUIT TO THE PROBE.

DIVISION 2 INSTALLATION
CANADIAN STANDARDS



INSTALLATION (CSA) TXA/TXR TRANSMITTER	
8093 CONN. INS.	5688
SHEET 7 OF 7	

WIRING DIAGRAMS



Permanent wiring connection to the Dynamic Signal BNC connector is not allowed under the intrinsic safety certification requirements.

SPECIAL CONDITIONS OF SAFE USE (INTRINSICALLY SAFE)

Transmitter is certified as a component only and must be installed in a suitable enclosure acceptable to local authorities.

Field wiring from the safe area to the transmitter must conform with the local electrical code. The transmitter provides a non-sparking circuit to probe and extension cable, which therefore require no further electrical protection.

Do not use Dynamic Signal BNC connector unless area is known to be non-hazardous. The transmitter is not capable of withstanding the insulator test required by Clause 6.4.12 of EN50020:2002. This must be taken into account when installing the transmitter.

INPUT/OUTPUT PARAMETERS (INTRINSICALLY SAFE)

Terminals marked "POWER"

U_i	= 28V
I_i	= 93mA
P_i	= 0.66W
C_i	= 18nF
L_i	= 0uH

External Probe Connector, J1 marked "PROBE"

CSA Parameters	
V_{oc}	= 5.36V
Disc	= 3.61mA
C_a	= 512uF
L_a	= 1000uH
P_o	= 19.4mW

NON-INCENDIVE INSTALLATION IN HAZARDOUS LOCATIONS



Non-Incendive
Class I, Div. 2, Groups A, B, C, D
Temp Code T4 ($-40^{\circ}\text{C} \leq T_a \leq +85^{\circ}\text{C}$)

Connect the field wiring in accordance with Metrix drawing 9688 (page 2) for CSA Class I, Div 2 installations. Transmitter is certified as a component only and must be installed in a suitable enclosure acceptable to local authorities. Field wiring from the safe area to the transmitter must conform with the local electrical code. The transmitter provides a non-incendive circuit to probe and extension cable, which therefore require no further electrical protection. Do not use Dynamic Signal BNC Connector unless area is known to be non-hazardous.

CALIBRATION AND SIGNAL ANALYSIS

1. Each transmitter has been factory calibrated for use with the probe type and extension cable specified using a 4140 steel target material. The full scale 20 mA output (SPAN) is factory set to the full scale value indicated on the nameplate. Probes and extension cables of the same type may be exchanged with a maximum error of + 12% without recalibration of the transmitter. For maximum accuracy, calibrate the transmitter with the probe and cable to be used.



CAUTION: Do not connect test equipment or cables to the transmitter unless the area has been determined to be non-hazardous.

2. The Dynamic Output jack (BNC) is a buffered output from the transmitter. The probe gap can be set “electrically” to the center of its measurement range by observing the DC output voltage at the BNC connector with an isolated meter. Adjust the probe gap to obtain 10 VDC, which corresponds to a gap of approximately .050” (1.25 mm). **Once a 10VDC reading is obtained, it is recommended that power to the transmitter be cycled. This can be accomplished easily by disconnecting the terminal block at the transmitter.** If the reading changes significantly, adjust the probe to obtain a 10 VDC reading. The preferred static gap range for TXR units is .035” to .050”. This corresponds to a gap voltage of 7.5 VDC to 10 VDC. Note that for 11 mm probes, the voltage is 9 VDC.

3. The use of a ground isolated instrument or signal isolator is highly recommended. The meter, oscilloscope or analyzer used to measure the gap voltage or to observe the vibration signal (DYNAMIC OUTPUT) must have an input impedance of one megohm or greater. The output impedance of the DYNAMIC OUTPUT is 10,000 ohms. Use of a measuring instrument with an input impedance of less than one megohm will introduce a measurement error. See Graph 2.

3a. TXR Units: During normal operation with vibration input, the transmitter current output is linearly proportional to the full scale vibration range between 4 mA and 20 mA.

EXAMPLE:

Measured mA	Full Scale Vibration	Actual Vibration
<3.6	5.0 mils, pk-pk	Probe Fault
4.0	5.0 mils, pk-pk	0.0 mils, pk-pk
12.0	5.0 mils, pk-pk	2.5 mils, pk-pk
20.0	5.0 mils, pk-pk	5.0 mils, pk-pk

3b. TXA Units: The transmitter current output is linearly proportional to the probe gap (position) between 4 mA and 20 mA.


Example: A current of 12 mA represents a probe position of:
 $(12 \text{ mA} - 4 \text{ mA} / 16 \text{ mA}) \times 60 + 20 = (0.5 \times 60) + 20 = 50 \text{ mils}$.

To verify the correct operation of the position transmitter, the output current should be:

Low Check Point
 30 mils (0.75 mm) = 6.65 mA


High Check Point
 70 mils (1.75 mm) = 17.35 mA

 **NOTE:** Check points are 10 mils inside of specified range end points. Tolerance is + 0.15 mA. It is recommended that an out-of-tolerance transmitter be returned to the factory for recalibration.



Graph 2

Buffered Output Frequency Response vs. Cable Length Assuming Cable Capacitance of 47 pF/Ft



Graph 3

4. The transmitter cannot be repaired in the field and must be replaced by an equivalent unit. The transmitter is not to be exposed to dust conditions.
5. The transmitter should not be installed where it may be subjected to mechanical and excessive thermal stresses or where it may be attacked by existing or foreseeable aggressive substances.
6. The transmitter must be installed such that its terminals are protected to at least IP20.
7. The apparatus enclosure is made from plastic which must be protected from impact and friction.
8. Installer must perform a risk assessment in accordance with Clause 10 of EN60079-25 and install lightning protection arresters as deemed necessary.

ENVIRONMENTAL SPECIFICATIONS

Unless otherwise noted, all specifications are specified at 21°C (70°F), +24 VDC power supply, gap set to 1.27 mm (50 mils) and using Metrix AISI 4140 steel target.

Operating Temperature Range:

-40°C to 85°C (-40°F to 185°F)

Operating Humidity Range:

95% non-condensing, external environmental protection is required.

Power Requirements:

- 17 to 30 VDC with a maximum start up current of 20 mA (-40°C to 85°C)
- Maximum loop resistance is determined by $R_L = 50 (V_s - 17)$ ohms

Frequency Response:

- 5 Hz to 5 kHz +0, -3 dB pk-pk vibration (TXR)
- 0 Hz to 20 Hz +0, -3 dB position (TXA)

Linear Range:

- 0.5 to 2.0 mm (20 to 80 mils); (8 mm probe)
- 0.5 to 4.0 mm (20 to 160 mils); (11 mm probe)

Buffered Output:

- 7.87 V/mm (200 mV/mil) +/- 5% when calibrated as a system, +/- 12% including interchangeability error when measured in 0.25 mm (10 mils) increments over the linear range.
- 3.94 V/mm (100 mV/mil) +/- 5% for 11 mm probes when calibrated as a system, +/- 12% including interchangeability error when measured in 0.25 mm (10 mils) increments over the linear range.
- 0 Hz to 3 kHz +0, -3 dB



NOTE: This must be taken into account when installing the transmitter.

4-20 mA Output:

4 mA +/- 0.1 mA with no input vibration

4 mA +/- 0.2 mA @ -40°C to 85°C with no input vibration

20 mA +/- 0.5 mA @ -40°C to 85°C with full scale input vibration

< 3.6 mA indicates "Not OK" condition

Hazardous Area Ratings

- CSA Certified
 - Intrinsically Safe, Class I. Div. 1, Groups A, B, C & D, Temp Code T4
 - Non-Incendive, Class I. Div. 2, Groups A, B, C & D

ENVIRONMENTAL INFORMATION



This electronic equipment was manufactured according to high quality standards to ensure safe and reliable operation when used as intended. Due to its nature, this equipment may contain small quantities of substances known to be hazardous to the environment or to human health if released into the environment. For this reason, Waste Electrical and Electronic Equipment (commonly known as WEEE) should never be disposed of in the public waste stream. The “Crossed-Out Waste Bin” label affixed to this product is a reminder to dispose of this product in accordance with local WEEE regulations. If you have questions about the disposal process, please contact Metrix Customer Services.

info@metrixvibration.com

www.metrixvibration.com

8824 Fallbrook Dr. Houston, TX 77064, USA

Tel: 1.281.940.1802 • Fax: 1.713.559.9421

After Hours (CST) Technical Assistance: 1.713.452.9703